



NOTES:

- 1) CUT CABLE JUST ABOVE SWAGE ON "HANGMAN'S NOOSE".
- 2) SPREAD SLOT OPEN ON BEAD CHAIN COUPLER TO ALLOW CABLES TO ENTER.
- 3) CRIMP SLOT CLOSED IN BEAD CHAIN COUPLER AFTER CABLES ARE INSERTED.